


Moso® Engineered board with LOC system

Product

The MOSO Engineered board with LOC system consists of 3 layers, with a 4 mm bamboo top layer. The other layers are made of pine, the middle layer being cross pressed to maximise stability. The boards are connected by means of the „LOC“ system: the boards are machined in such a way that a fixed connection can be made without using glue.



Engineered board plain pressed LOC

Engineered board side pressed LOC

Product line

Code Natural	Code Caramel	Style	Edges	Finish	Dimensions (mm)	Box Content (Pcs.)	Box Content (m ²)
BF-SW320	BF-SW370	PP	SE	L	2200x190x15	8	3,344
BF-SW420	BF-SW470	SP	SE	L	2200x190x15	8	3,344
BF-SW321	BF-SW371	PP	SE	O	2200x190x15	8	3,344
BF-SW421	BF-SW471	SP	SE	O	2200x190x15	8	3,344

Stained:

Code White	Code Black	Style*)	Edges	Finish	Dimensions (mm)	Box Content (Pcs.)	Box Content (m ²)
BF-SW420WH	BF-SW470BL	SP	SE	L	2200x190x15	8	3,344

PP = plain pressed

SP = side pressed

SE = sharp edge

L = lacquer Bona 80 gr/m²

O = oil air dried Woca

Installation

Please read the full installation instructions on the backside.

This floor type can be installed – under certain conditions – on warm water floor heating. See “MOSO flooring and floor heating”.

Technical characteristics

- LOC system: Välinge (Berry)
- Hardness: 4,0 kg/mm² (Brinell)
- Shrink/swell: 0,14% per 1% change in moisture content
- Equilibrium MC: 10% at 20 °C and 65% Rel. Air Humidity
8% at 20 °C and 50% Rel. Air Humidity
- Density (bamboo): 700 kg / m³
- Emission formaldehyde: <0,124 mg/m³ (E1 norm)



Installation instruction MOSO® Engineered board LOC

Before installation

- To allow acclimatisation, lay your bamboo flooring flat in the room in which it is to be installed for at least 48 hours, in its sealed foil packaging or box, at a room temperature of 18°-20°C (50-65% air humidity).
- Please note that the surface to which the flooring is to be applied must have a minimum temperature of 18°C. The flooring may be installed on any sub floor which is level, without cracks, dry, clean and stable.
- Excessive humidity has a detrimental effect on the flooring. Maximum permitted humidity levels for sub floors are: sand cement 1,8%, chipboard 7-9%, anhydrite floors 0.3%.
- We recommend that you use PE damp proof membrane (min 0.2mm). The membrane must overlap by 30 cm.
- We recommend that you use a sound isolating underlay like a PE-foam.

Please note

- Bamboo is a natural product! Therefore variations in colour and structure within a batch are possible. You should always mix the components from different boxes.
- Before installation, we advise you to inspect the flooring for moisture content, size, colour differences and damage. We cannot accept any complaints regarding this once the material has been installed or further processed.
- Installation of the flooring should always be the final job in any building project, in order to avoid damaging the flooring surface. Take care when working with adhesive tape as this could damage the flooring finish.
- Felt pads must be attached to furniture and chairs to avoid damage to the flooring surface.
- To protect against dust and sand, a walk-off mat has to be placed before and after the entrance of the room.

Ideal room conditions







- Room temperature approx. 18-20°C; Air humidity 50 - 65%.
- During the winter months, room air can become extremely dry. To maintain a constant air humidity, ceramic humidifiers should be mounted on radiators (or stoves) and, for larger rooms, electric air humidifiers are required. In summer and autumn when air humidity is high, ensure that the room is well-ventilated. Where these conditions are not maintained, warping, shrinkage and movement will occur. Check the air humidity using a hygrometer.

Expansion gap

- This floor type is laid as a floating floor, see the following installation instructions. Fully glueing the boards to the subfloor is also a possible installation method, but this requires specialist materials and skills; therefore a recognised contractor should carry out the installation.
- Bamboo and wood are natural products which are affected by air humidity. Excessive air humidity causes bamboo materials to swell whilst low air humidity results in shrinking. It is of the utmost importance that you maintain distance (expansion gap) from walls, door frames, pipes etc. This distance should be minimal 10-15 mm. If the floor is wider than approx. 7 metres or longer than approx. 12 metres, a larger expansion gap must be included.

Floor heating

This floor type can be installed – under certain conditions – on warm water floor heating. See “MOSO flooring and floor heating”.

					
Place the first board, in the left side of the room, with the tongue side against the wall.	Connect the next board on the head-side: insert the tongue under a 45 degree angle and press it to the floor. Continue to install the rest of the row in the same manner.	Start the second row with the off-cut from the last board installed. Remember to stagger the end joints of the boards in adjacent rows by at least 50cm.	Put an installation wedge under the short end of the last board installed.	Connect the next board on the head-side: insert the tongue under a 45 degree angle and press it down, at the same time inserting the tongue on the length side of the board.	Carefully tap the boards together using a hammer and tapping block. Remove the installation wedge and gently push the boards down to the floor. Continue to install the rest of the floor in the same manner.

Maintenance and cleaning

- Initial maintenance: in case of a pre finished floor (lacquered or oiled), initial maintenance should be carried out after installation is complete.
- Cleaning and care: The useful life of your bamboo floor will be considerably increased with suitable cleaning and maintenance.
- For further information, look at www.woodcaredenmark.com for pre-oiled and www.bona.com for pre-lacquered finishes.

Skirting boards

Skirting boards must be fixed to the walls with screws and plugs in such a way as not to obstruct the natural movement of the wooden floor. If skirting boards are fixed to the wooden floor they will obstruct the floor's natural movement, and may, therefore, cause damage.

Additional note

Whilst all due care is taken to ensure the accuracy of the installation instructions, individual circumstances (location, subfloor and installation procedures) may vary and are beyond the manufacturer's control. In case of doubt, therefore, consult the distributor.

These instructions are subject to change. For the latest version go to www.moso.eu.